

# How to Lay Bricks with Westbuild High Strength M4 Mortar



## Ideal for

- Construction within 1km of coastline or 100m of river waters - M4 Classification
- Retaining walls, in aggressive soils or for use below the damp proof course (DPC)
- Commercial, industrial and residential brick and block work

## How much to use

- 1x 20kg bag is sufficient to lay approximately 20 standard bricks
- If using as a single coat render, 20kg will cover 1m<sup>2</sup> at 10mm thick

## Tools you will require

- Bucket
- Shovel
- Brickies trowel, finishing tools
- Wheelbarrow, mud board or mixer
- Spirit level and string line
- Wooden float or steel trowel if rendering



Please turn over for  
full application details

Available at  
**BUNNINGS**  
warehouse  
[bunnings.com.au](http://bunnings.com.au)

## Step 1 – Prepare

- Measure and plan the quantity or where the mortar is to be used prior to any works
- Ensure you have adequate spare material as some wastage will occur if laying for the first time

## Step 2 – Mix the mortar

- Empty contents of bag into the barrow or onto the non-porous mixing board
- Slowly add water until a workable mixture is achieved
- Westbuild M4 Mortar is pre-blended and only requires the addition of water



## Step 3 – Building the wall

- When laying bricks, first lay a trowel length of mortar where the brick is to be placed. Using the tip of your trowel, work a V shape through the centre to ensure mortar reaches the edge of the brick
- As each brick is laid ensure you ‘butter’ the end
- A string line properly set will ensure a straight wall is built, using a spirit level will also ensure you wall stays level and true



## Step 4 – Important Information

- Always check with your local council to comply with regulations
- Brick ties and building straps should be used where required
- Refer to TDS for more specific instructions
- Refer to SDS before using Westbuild M4 Mortar



If you require any assistance with this product, its installation or any other Westbuild product, please feel free to contact Westbuild on 08 9309 2029.